



1. Plug the phone line in from the wall to the “Line” port on the surge protector.
2. From the “Equip” port on the surge protector plug the second phone line in on the “Line” port of the modem.
3. From the “Equip” port on the modem plug the Ethernet cord in from the modem to the Ethernet port on the computer.
4. Plug all power cords of the equipment in the surge protector if possible. Plug the power cord from the surge protector to the wall outlet.

“ Make sure your internet options is set to never dial a connection”

“Self Install Modem Only”

Date 6/8/06