



1. Plug the phone line in from the wall to the "Line" port on the surge protector.
2. From the "Equip" port on the surge protector plug the second phone line in on the "Line" port of the modem.
3. From the "Equip" port on the modem plug the Ethernet cord in from the modem to the Ethernet port on the Router.
4. From the Ethernet port on the Router plug the Ethernet cord to the Ethernet port on the computer.
5. Plug all power cords of the equipment in the surge protector if possible. Plug the power cord from the surge protector to the wall outlet.

"Self Install Modem and Router"

Date 6/8/06